

M-1 Adhesive Cartridge Instructions for Use With Cretex PRO-RING



1. Cut the end of the cartridge off at the straight groove above the threads as shown above.



2. Cut the end of the tip off at the widest point just above the shoulder as shown above.



*****NOTE:** It is critical that the cartridge and tip be cut off as shown above to allow the maximum flow of the adhesive and prevent a blowout through the rear of the cartridge.